Page: 1 A2064 3M - Dual Driveaway Kit instructions

Thank you

for purchasing this product. At Quest we take every care to ensure that the product fulfils your expectations. We hope you enjoy using this product

General Use

Please read this user guide before attempting to fit your connection kit. Follow the user guide carefully and keep for future reference.

Content

- 1 x 3M Dual Kador Strip (4&6/6mm).
- 4 x 75cm Figure of eight connectors
- 1 x Storage bag

Care and Cleaning Instructions

- Allow material to dry completely before storing in the storage bag provided. Remove dirt with a soft sponge and warm water.
- DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.

Fitting Guide

- Insert the kador strip into the awning channel on your vehicle. Ensure the correct size beading is inserted (either 6mm or 4mm).
- Thread the 4 x figure of 8 extrusions onto the kador strip.
- NOTE: You can trim the kador strip and figure of eight connectors to fit your vehicle size if required.
- You can now insert your awning to the open edge of the figure of 8 connectors.



Quest manual download site

The quest manual download site can be found at the url below or the QR code to the left

http://www.questleisure.com/manuals.